



HAND WARMER



40182
Handwarmer

44003
Replacement Burner

Hand Warmer

One
Fill
Using the included filler cup, fill the hand warmer with Zippo® Lighter Fluid.

Two
Replace Lid
The high-polish finish and sleek, thin design stays warm for up to 12 hours.

Three
Ignite
Ignite the catalytic burner on top of the Hand Warmer with a Zippo® Pocket Lighter.

Four
Place in Pouch
Slide the Hand Warmer in the fleece bag included.

Your customers want to be able to enjoy the Great Outdoors even when it's cold outside. And that's why we built our rugged, metal hand warmer. It has a high-polish finish and a sleek, thin design so it easily fits into pockets, and it's virtually odorless (great for hunters) and stays warm for up to 12 hours. Plus, it's reusable with Zippo lighter fluid and includes a convenient filler cup and warming bag. So whether your customers are going hunting or hitting the slopes, our hand warmer will keep them warm while they're at it.



44000
Campfire Starter

CAMPFIRE STARTER CEDAR PUCKS